

XG2 TEST OSCILLATOR MANUAL ERRATA

Rev F-2, March 18, 2015

**THE FOLLOWING CHANGES TO THE XG2 MANUAL
MUST BE MADE BEFORE PROCEEDING,
OR THE XG2 MODULE WILL NOT FUNCTION CORRECTLY**

- 1. Page 1, Specifications:** On the Frequency line, change the frequency tolerance from +/-1 kHz to +/- 2 kHz.
- 2. Page 1, Parts Inventory:** This section of the parts list replaces the one on page 1 in the manual on page 1:
(You can cut this out and pasted it in the manual.)

Ref	Qty	Description	Part #
R2	1	Res, 18.7 k 1% (brn, gry, vio, red, brn)	E500127
R3	1	Res, 16.5 Ω 1% (brn, blu, grn, gold, brn)	E500122
R4	1	Res, 348 Ω 1% (org, yel, gry, blk, brn)	E500123
R5	1	Res, 57.6 Ω 1% (grn, vio, blu, gold, brn)	E500124
R6, R7	2	Res, 52.3 Ω 1% (grn, red, org, gold, brn)	E500125
R8	1	Res, 1.24 k 1% (brn, red, yel, brn, brn)	E500126

- 3. Page 8, Schematic Diagram:** Change the value of R8, near the right end, from 1270 to 1240.